



Switching the G12 to Diagnosis Mode (PAD)

MODEL

G12 (7 Series Sedan)

INFORMATION

With the introduction of the new G12 7 series vehicle, a new terminal control concept was introduced. Please refer to the attached document which explains this in further detail.

In order to switch the vehicle into diagnosis mode (Terminal 15 in the past), either for diagnosis with ISTA or programming or coding with ISTA/P, **the Start/Stop button needs to be pressed 3 times in succession within .8 seconds**. The vehicle will then switch over to diagnosis mode (PAD) Testing Analysis Diagnosis.

In order to switch the vehicle into diagnostic mode for the State Inspection Maintenance Program, **the Start/Stop button must also be pressed 3 times in succession within .8 seconds**.

Additionally if a diagnosis session is started with ISTA and the vehicle is in "Residing" mode, ISTA automatically switches the vehicle to diagnosis mode (PAD).

ATTACHMENTS

View PDF attachment [B070315 Attachment](#).

[Copyright ©2015 BMW of North America, Inc.]